

FULL SCREEN INSTALLATION & REMOVAL GUIDE

STEP 1

While keeping the sides compressed, place one top corner of the screen into the screen track.

STEP 2

Keeping both sides compressed, place the opposite top corner into the screen track.


STEP 3


Continue to keep sides compressed, and insert screen into a bottom corner. (Lift slightly if your window has a lip on the sill.) Release this side of the screen.


STEP 4

Place the last corner into the screen track and release completely once all corners are in place.









STEP 1

Gently press on the center of the screen until you can wrap your hands around the FlexScreen frame. Squeeze both sides inward 4"-6".



While keeping the sides compressed, lift the screen up and remove one of the bottom corners from the screen track.

STEP 3

Remove the opposite bottom corner from the screen track.



With both corners out of the screen track, pull Flex-Screen down from the top and remove the screen.



